

## Pflegehinweise - Metall-Backzubehör - Le Creuset

### ENGLISH

Before first use remove packaging, hand wash in warm soapy water and dry thoroughly. Metal kitchen utensils may be used with care. Knives or utensils with sharp edges should not be used. Do not use abrasive cleaners. Not suitable for microwave ovens, dishwasher, grill or use on direct heat. After washing, water trapped inside the rim may cause slight rusting. This is a natural trait of carbon steel, not a fault, and will not affect the performance of the product.

### GERMAN

Reinigen Sie die Backform vor dem 1. Gebrauch mit warmem Wasser und Spülmittel und trocknen Sie sie ab. Metall-Küchenhelfer können mit Vorsicht verwendet werden. Messer oder scharfkantige Küchenhelfer sollten nicht verwendet werden. Keine aggressiven Reinigungsmittel verwenden. Nicht geeignet für Mikrowellen, Spülmaschinen, Grills oder direkte Hitzequellen. Wenn sich Spülwasser an der Unterseite des Randes ansammelt kann dies dort zu leichten Roststellen führen. Dies ist eine natürliche Eigenschaft von Kohlenstoffstahl, kein Fehler und wird die Leistung des Produktes nicht beeinflussen.